


Maytag MFR40PDCTS 02 - CABINET (PD)



25-Feb-05
519 390

Maytag [Residential Maytag MFR40PDCTS Washer Parts](#) Parts Diagram 02 - CABINET (PD)
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	23004176			Left Side Panel Complete
002	23004177			Right Side Panel Complete
003	23004178			Front Panel Comp
"	23004515			Front Panel, Mfr40-50pd
005	23002857			Panel, Service
006	23004179			Rear Cover
007	23004180			Left Support Rail
008	23004181			Right Support Rail
009	23004182			Rear Cover Holder
010	23002461			Screw
011	23002462			Screw Lu
012	23002861			Screw Lu
013	23002456	23003478		Screw
014	23003773		Not Available	NUT M6
015	23003716			Nut M5
016	23002471	23001310		Nut, Self Locking

017	23002862	23001708	Washer
018	23003778	23002756	Lockwasher
019	23002440		Washer, Spring Lock
020	23002756		Lockwasher
021	23003012		Washer Lu
022	23004092	23001575	Nut, Insert
023	23002455		Nut, Rapid
024	23002457		Washer M6
026	23001447		Washer, Fiber
028	23001330		Rod, Top Panel Support
029	23004183		Pin, Alignment
030	23002860		Tube, Distance

rows
the laundry company[®]

rows
the laundry company[®]

rows
the laundry company[®]