


# Maytag MFR40PNCTS 07 - CONTROL PANEL (PN)



23-Sep-05  
521449A

Maytag [Residential Maytag MFR40PNCTS Washer Parts](#) Parts Diagram 07 - CONTROL PANEL (PN)  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">23004191</a>			Bracket, Control Panel Mfr40-50
002	<a href="#">23004192</a>			Control Panel PNMFR40-50
003	<a href="#">23003991</a>			Mcg Controller
004	<a href="#">W10165009</a>			MC4 Coin Program Chip
"	<a href="#">W10304859</a>			Programming Chip W/Software
005	<a href="#">23004133</a>			Key Board, Full Control
006	<a href="#">23004134</a>			Spacer M3xm5x3
007	NLA		Not Available	COVER, PLASTIC
008	23004135		Not Available	MAYTAG LABEL
009	23003810	<a href="#">W10131119</a>		Screw, 8-18 X 5/16
010	<a href="#">23004126</a>			Double Sided Tape
011	<a href="#">23001145</a>			Microswitch, Lever
012	<a href="#">23003653</a>			Spacer
013	<a href="#">23003652</a>			Screw, Switch
014	<a href="#">23003654</a>			Washer M3.2
015	<a href="#">23002958</a>			Nut M3

016	<a href="#">23003871</a>		Mounting Bracket
017	<a href="#">23002438</a>		Washer M4.3
018	23002330	Not Available	LABEL, CENTRAL STOP
019	<a href="#">23002950</a>		Lock Washer M4
020	23003666	<a href="#">23001014</a>	Nut M4
021	<a href="#">23004136</a>		Stop Button Emergency
022	<a href="#">23004137</a>		Contact Block
023	23002452	<a href="#">8184504</a>	Nut
024	<a href="#">23002869</a>		Screw
025	23002862	<a href="#">23001708</a>	Washer
026	<a href="#">23002836</a>		Washer
027	NLA	Not Available	LOCKWASHER (M3)
028	<a href="#">23004138</a>		Soap Supply Label
029	<a href="#">23004139</a>		Emergency Stop Harness

