


Maytag MFW9600SQ1 03 - CONTROL PANEL PARTS

CONTROL PANEL PARTS

For Model: MFW9600SQ1

(White)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

W10133063

5

[Maytag Residential Maytag MFW9600SQ1 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8183082			Panel, Control
2	8182150			User Interface
3	8183077	W10163302		Button, Power
4	8182183	2004333		Nut
5	8182604			Button Set, Left
6	8183084			Button Set, Middle
7	8182602			Button Set, Right
8	8183081	W10163306		Button Set, Start
9	8182224		Not Available	Brace, Front Top
10	8181640	8182800		Channel, Water
11	W10137701			Microcomputer, Machine Control
12	8181756	488729		Screw
13	8182212			Harness, Wiring
14	8182171			Bezel, Knob
15	8183083			Overlay, Door
16	8183059	W10098820		Medallion

17	8183076	W10163301	Knob, Control
18	8182599		Endcap, Left
19	8182600		Endcap, Right
20	8183057		Handle, Drawer

