


# Maytag MFW9700SB0 03 - CONTROL PANEL PARTS

## CONTROL PANEL PARTS

For Models: MFW9700SQ0, MFW9700SB0  
(White) (Black)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

W10112155

5

Maytag [Residential Maytag MFW9700SB0 Washer Parts](#) Parts Diagram 03 - CONTROL PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8183056</a>			Panel, Control
"	<a href="#">8183071</a>			Panel, Control
2	<a href="#">8182150</a>			User Interface
3	<a href="#">8182601</a>			Button, Power
"	8183077	<a href="#">W10163302</a>		Button, Power
4	8182183	<a href="#">2004333</a>		Nut
5	<a href="#">8182604</a>			Button Set, Left
"	<a href="#">8183080</a>			Button Set, Left
6	<a href="#">8182603</a>			Button Set, Middle
"	<a href="#">8183079</a>			Button Set, Middle
7	<a href="#">8182602</a>			Button Set, Right
"	8183078	<a href="#">W10163303</a>		Button Set, Right
8	<a href="#">8182180</a>			Button Set, Start
"	8183081	<a href="#">W10163306</a>		Button Set, Start
9	8182224		Not Available	Brace, Front Top
10	8181640	<a href="#">8182800</a>		Channel, Water

11	8182774	<a href="#">W10137702</a>	Microcomputer, Machine Control
12	8181756	<a href="#">488729</a>	Screw
13	<a href="#">8182212</a>		Harness, Wiring
14	<a href="#">8182171</a>		Bezel, Knob
15	<a href="#">8183058</a>		Overlay, Door
"	<a href="#">8183075</a>		Overlay, Door
16	8183059	<a href="#">W10098820</a>	Medallion
17	8182175	<a href="#">W10163301</a>	Knob, Control
"	8183076	<a href="#">W10163301</a>	Knob, Control
18	<a href="#">8182599</a>		Endcap, Left
"	<a href="#">8183073</a>		Endcap, Left
19	<a href="#">8182600</a>		Endcap, Right
"	<a href="#">8183074</a>		Endcap, Right
20	<a href="#">8183057</a>		Handle, Drawer
"	<a href="#">8183072</a>		Handle, Drawer

