


# Maytag MFW9700SQ1 02 - DOOR AND LATCH PARTS

## DOOR AND LATCH PARTS

For Models: MFW9700SQ1, MFW9700SB1  
(White) (Black)



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

W10133064

3

[Maytag Residential Maytag MFW9700SQ1 Washer Parts](#) Parts Diagram 02 - DOOR AND LATCH PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8182210</a>			Clamp, Bellow
2	<a href="#">8182119</a>			Bellow
3	<a href="#">8182634</a>			Lock, Door
4	8181760	<a href="#">8540725</a>		Screw
5	<a href="#">8182211</a>			Clamp, Bellow To Front Panel
6	8181758	<a href="#">8182214</a>		Screw
7	<a href="#">8181651</a>			Hook, Door
8	<a href="#">8181661</a>			Screw, Actuator
9	<a href="#">8181660</a>			Screw
10	8182628	<a href="#">W10163308</a>		Frame
11	<a href="#">W10128586</a>			Clamp, Glass Support
12	<a href="#">8181650</a>			Clamp, Glass
13	<a href="#">8181655</a>			Glass, Door
14	<a href="#">8181843</a>			Hinge, Door
15	<a href="#">8182151</a>			Frame, Door Front Assembly
"	<a href="#">8183070</a>			Frame, Door Front Assembly

16	<a href="#">8182779</a>	Clip, Trim
17	<a href="#">8182592</a>	Trim, Upper Left
"	<a href="#">8183065</a>	Trim, Upper Left
18	<a href="#">8182595</a>	Cover, Hinge
"	<a href="#">8183067</a>	Cover, Hinge
19	<a href="#">8182596</a>	Cover, Hinge
"	<a href="#">8183068</a>	Cover, Hinge
20	<a href="#">8182594</a>	Trim, Lower
"	<a href="#">8183066</a>	Trim, Lower
21	<a href="#">8182591</a>	Handle, Door
"	<a href="#">8183069</a>	Handle, Door
22	<a href="#">8182593</a>	Trim, Upper Right
"	<a href="#">8183064</a>	Trim, Upper Right
23	<a href="#">8182153</a>	Foam, Door Handle
24	8181759	<a href="#">3400805</a> Screw, 8-18 X 3/64

