


Maytag MFX100PAVS 08 - DOOR



Maytag [Residential Maytag MFX100PAVS Washer Parts](#) Parts Diagram 08 - DOOR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	23001916			Frame, Door
002	NLA		Not Available	NUT, FRAME
003	23001918			Door, Loading
004	23001919			Latch, Door
005	23001920			Cover
006	23001921			Washer
007	23001922			Shim
008	23001923			Doorglass
009	23001924			Gasket, Glass
010	23001925			Doorseal
011	NLA		Not Available	SCREW (M6X10)
012	23001374	23002462		Screw Lu
013	23001677			Nut
014	23001158			Lockwasher
015	23001668			Contact, Magnetic
016	23001624			Connection, Elbow

017	23001625		Adapter, Doorshower Fitting
018	23001623		Adapter, Hose Fitting
019	23001626		Washer, Shower
020	23001628		Shower, Door
021	23001931		O-Ring
022	23001932		Bolt
023	23001670		Washer
024	23001934		Hinge
025	23001935		Hinge
026	23001936		Doorlock Assembly
027	23001937		Shield, Front
028	23001938		Adapter, Hinge
029	23001643	23002424	Washer M6.4
030	23001939		Shim, Hinge
031	NLA	Not Available	SHIM, DOORLOCK
032	23001941		Washer, Hinge
033	23001641	23002461	Screw
034	23001034	Not Available	NUT (M6)
035	23001631	23002727	Washer Lu
036	23001602		Bolt, Lentil Cup
037	23001622		Shower, Support Door
038	NLA	Not Available	BOLT (M6X12)
039	23001630		Hose, Water Inlet
040	23002124	Not Available	LABEL, HEAT WARNING

