


Maytag MGD5707TQ1 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: MGD5707TQ1
(White)

29" GAS DRYER



7-07 Litho in U.S.A.(LT)

1

Part No. W10155375 Rev.A.

Maytag [Residential Maytag MGD5707TQ1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10089177		Not Available	Sheet, Cycle Feature
"	W10088775		Not Available	Use & Care Guide
2	W10124166			Wire, Jumper
3	694419			Mini-Buzzer
4	W10112603			Seal, Harness
5	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	W10112577			Panel, Rear Console
7	8530169			Switch, Temperature
8	3398094			Switch, Push To Start
9	8566184			Timer Assembly
10	8565972			Screen, Lint
11	8536939			Clip, Knob
12	359625	487240		Screw, For Mtg. Service Capacitor
13	688983	487240		Screw, For Mtg. Service Capacitor

14	W10112599		Top
15	237446	487596	Washer
16	W10111000		Harness, Wiring
17	717252		Receptacle, Terminal
18	94614		Terminal
19	3394427		Clip-Harness
20	W10112578		Harness, Bracket
21	693995		Screw, Hex Head
22	8558178		Control, Electronic
23	3391885		Connector, Edge
24	3397269		Connector, Timer
25	3401144		Connector
26	3403499		Connector, 2-Postion
27	3403498		Connector, 3-Position
28	3405156		Switch, Rotary
29	3395683		Receptacle, Multi-Terminal
30	337686	Not Available	SCREW, 8-18 X .500
31	W10112582		Knob, Control Assembly
32	W10112586		Knob Assembly Push-To-Start
33	3347243		Block, Disconnect
34	3936144		Do-It-Yourself Repair Manuals
35	W10086730	W10142686	Console
36	8312709		Clip-Console
38	W10112584		Knob, Timer Assembly

the laundry company[®]

the laundry company[®]