


Maytag MGD5721TQ0 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: MGD5721TQ0
(White)

29" GAS DRYER



11-07 Litho in U.S.A. (LAN)

1

Part No. W10136018 Rev. B

Maytag [Residential Maytag MGD5721TQ0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10150648		Not Available	Sheet, Cycle Feature
"	W10151609		Not Available	Use & Care Guide (English)
"	8578889		Not Available	Wiring Diagram
2	W10113080			Wire, Jumper
3	694419			Mini-Buzzer
4	W10118608			Foam-Seal Console Bracket
5	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	W10112576			Panel, Rear Console
7	3405155			Switch, Temperature
8	W10117655			Switch, Push-To-Start
9	8566184			Timer Assembly
10	8565972			Screen, Lint
11	8536939			Clip, Knob
12	359625	487240		Screw, For Mtg. Service Capacitor
13	688082	487240		Screw, For Mtg. Service

13	000903	407440	Capacitor
14	W10112599		Top
15	237446	487596	Washer
16	W10113074		Harness, Wiring
17	717252		Receptacle, Terminal
18	W10112267		Foam-Seal Control Bracket
19	3394427		Clip-Harness
20	8565981		Bracket, Harness
21	693995		Screw, Hex Head
22	8558178		Control, Electronic
23	3391885		Connector, Edge
24	3397269		Connector, Timer
25	3401144		Connector
26	3403499		Connector, 2-Postion
27	3403498		Connector, 3-Position
28	3405156		Switch, Rotary
29	3395683		Receptacle, Multi-Terminal
30	337686	Not Available	SCREW, 8-18 X .500
32	3347243		Block, Disconnect
33	W10086726	Not Available	Console & Control Panel Assembly (Includes Items 12 & 27)
34	8312709		Clip-Console
35	W10112569	W10203949	Medallion
36	W10110030		Timer Knob Assembly
37	W10110029		Knob, Control
38	94614		Terminal
39	3936144		Do-It-Yourself Repair Manuals

the laundry company[®]

the laundry company[®]