


Maytag MGD5740TQ1 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: MGD5740TQ1
(White)

29" GAS DRYER



7-07 Litho in U.S.A.(LT)

1

Part No. W10155372 Rev. A

Maytag [Residential Maytag MGD5740TQ1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10089171		Not Available	Sheet, Cycle Feature
"	W10088775		Not Available	Use & Care Guide
"	W10118081		Not Available	Wiring Diagram
2	W10113080			Wire, Jumper
3	694419			Mini-Buzzer
4	W10112603			Seal, Harness
5	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	W10112577			Panel, Rear Console
7	3405155			Switch, Temperature
8	W10117655			Switch, Push-To-Start
9	8566184			Timer Assembly
10	8565972			Screen, Lint
11	8536939			Clip, Knob
12	359625	487240		Screw, For Mtg. Service Capacitor
13	688082	487240		Screw, For Mtg. Service

13	000903	407440	Capacitor
14	W10112599		Top
15	237446	487596	Washer
16	W10110996		Harness, Wiring
17	717252		Receptacle, Terminal
18	W10112578		Harness, Bracket
19	3394427		Clip-Harness
20	337686	Not Available	SCREW, 8-18 X .500
21	693995		Screw, Hex Head
22	8558178		Control, Electronic
23	3391885		Connector, Edge
24	3397269		Connector, Timer
25	3401144		Connector
26	3403499		Connector, 2-Postion
27	3403498		Connector, 3-Position
28	3405156		Switch, Rotary
29	3395683		Receptacle, Multi-Terminal
30	W10110029		Knob, Control
31	94614		Terminal
32	3936144		Do-It-Yourself Repair Manuals
33	3347243		Block, Disconnect
35	W10086722	W10142688	Console
36	8312709		Clip-Console
37	W10112569	W10203949	Medallion
38	W10110030		Timer Knob Assembly

