


Maytag MGD5770TQ1 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: MGD5770TQ1
(White)

29" GAS DRYER



10-07 Litho in U.S.A.(LAN)

1

Part No. W10169548 Rev. A

Maytag Residential Maytag MGD5770TQ1 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10089171		Not Available	Sheet, Cycle Feature
"	W10088775		Not Available	Use & Care Guide
"	8578889		Not Available	Wiring Diagram
2	W10113080			Wire, Jumper
3	694419			Mini-Buzzer
4	W10086728	W10173390		Console
5	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	W10112577			Panel, Rear Console
7	3405155			Switch, Temperature
8	W10117655			Switch, Push-To-Start
9	8566184			Timer Assembly
10	8565972			Screen, Lint
11	8536939			Clip, Knob
12	W10110029			Knob, Control
13	W10110030			Timer Knob Assembly
14	W10112599			Top

15	237446	487596	Washer
16	W10110996		Harness, Wiring
17	359625	487240	Screw, For Mtg. Service Capacitor
18	W10112578		Harness, Bracket
19	337686	Not Available	SCREW, 8-18 X .500
20	688983	487240	Screw, For Mtg. Service Capacitor
21	693995		Screw, Hex Head
22	8558178		Control, Electronic
23	3391885		Connector, Edge
24	3405156		Switch, Rotary
25	8312709		Clip-Console
26	W10112569	W10203949	Medallion
27	W10112603		Seal, Harness
29	717252		Receptacle, Terminal
30	3395683		Receptacle, Multi-Terminal
31	3394427		Clip-Harness
32	3397269		Connector, Timer
33	3401144		Connector
34	3403499		Connector, 2-Position
35	3403498		Connector, 3-Position
36	3347243		Block, Disconnect
37	94614		Terminal
38	3936144		Do-It-Yourself Repair Manuals

the laundry company[®]

the laundry company[®]