


Maytag MGD5800TW0 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: MGD5800TW0
(White)

29° GAS DRYER



10-07 Litho in U.S.A.(dtd)

1

Part No. W10118235 Rev. B

Maytag [Residential Maytag MGD5800TW0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10150648		Not Available	Sheet, Cycle Feature
"	W10151609		Not Available	Use & Care Guide (English)
"	W10118081		Not Available	Wiring Diagram
2	W10113080			Wire, Jumper
3	694419			Mini-Buzzer
4	W10086711	W10142689		Console
5	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	W10112576			Panel, Rear Console
7	8530169			Switch, Temperature
8	W10117655			Switch, Push-To-Start
9	8566184			Timer Assembly
10	8565972			Screen, Lint
11	8536939			Clip, Knob
12	W10110035			Knob
13	W10110036			Knob
14	W10112599			Top

15	237446	487596	Washer
16	W10120796		Harness, Wiring
17	359625	487240	Screw, For Mtg. Service Capacitor
18	8565981		Bracket, Harness
19	337686	Not Available	SCREW, 8-18 X .500
20	688983	487240	Screw, For Mtg. Service Capacitor
21	693995		Screw, Hex Head
22	8558178		Control, Electronic
23	3391885		Connector, Edge
24	3405156		Switch, Rotary
25	8312709		Clip-Console
26	W10112569	W10203949	Medallion
27	W10118608		Foam-Seal Console Bracket
28	W10112267		Foam-Seal Control Bracket
29	717252		Receptacle, Terminal
30	3395683		Receptacle, Multi-Terminal
31	3394427		Clip-Harness
32	3397269		Connector, Timer
33	3401144		Connector
34	3403499		Connector, 2-Postion
35	3403498		Connector, 3-Position
36	3347243		Block, Disconnect
37	94614		Terminal
38	3936144		Do-It-Yourself Repair Manuals

the laundry company[®]

the laundry company[®]