


Maytag MGD5821TW0 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: MGD5821TW0
(White)

29" GAS DRYER



11-07 Litho in U.S.A. (LAN)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1

Part No. W10118489 Rev. B

[Maytag Residential Maytag MGD5821TW0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS](#)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10150648		Not Available	Sheet, Cycle Feature
"	W10151609		Not Available	Use & Care Guide (English)
"	8576803		Not Available	Wiring Diagram
2	W10113080			Wire, Jumper
3	694419			Mini-Buzzer
4	W10112267			Foam-Seal Control Bracket
5	8533971	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	W10112576			Panel, Rear Console
7	3405155			Switch, Temperature
8	W10117655			Switch, Push-To-Start
9	3406725			Timer Assembly
10	8565972			Screen, Lint
11	8536939			Clip, Knob
12	359625	487240		Screw, For Mtg. Service Capacitor
13	688082	487240		Screw, For Mtg. Service

13	000903	407440	Capacitor
14	W10112599		Top
15	237446	487596	Washer
16	W10113073		Harness, Wiring
17	717252		Receptacle, Terminal
18	8565981		Bracket, Harness
19	3394427		Clip-Harness
20	337686	Not Available	SCREW, 8-18 X .500
21	693995		Screw, Hex Head
22	8558178		Control, Electronic
23	3391885		Connector, Edge
24	3397269		Connector, Timer
25	3401144		Connector
26	3403499		Connector, 2-Position
27	3403498		Connector, 3-Position
28	3405154		Switch Rotary
29	3395683		Receptacle, Multi-Terminal
30	W10118608		Foam-Seal Console Bracket
33	3347243		Block, Disconnect
35	W10086714	Not Available	Console & Control Panel Assembly (Includes: Item 37.)
36	8312709		Clip-Console
37	W10112569	W10203949	Medallion
38	W10110036		Knob
39	W10110035		Knob
40	94614		Terminal
41	3936144		Do-It-Yourself Repair Manuals

the laundry company[®]

the laundry company[®]