


# Maytag MGD5870TW0 02 - CABINET PARTS



Maytag [Residential Maytag MGD5870TW0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	697776	<a href="#">4331106</a>		Screw, No.10-32 X 7/16
2	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
3	<a href="#">693995</a>			Screw, Hex Head
4	<a href="#">8541400</a>			Bracket, Cabinet
5	<a href="#">3396795</a>			Cover, Terminal Block
6	<a href="#">3404162</a>			Clamp, Motor
7	3396805	<a href="#">280043</a>		Panel-Rear
8	<a href="#">3403630</a>			Plug, Strike Hole
9	<a href="#">3980175</a>			Clamp, Elbow
10	<a href="#">3406107</a>			Door Switch Assembly
11	697773	<a href="#">3395530</a>		Screw
12	<a href="#">98669</a>			Lock, Front Top
13	<a href="#">341029</a>			Clamp, Pipe Door Spring
14	<a href="#">3404413</a>			Plug, Hinge Hole
15	<a href="#">18849</a>			Pad, Top Hinge
16	3392100	<a href="#">49621</a>		Feet-Leveling

"	<a href="#">279810</a>		Foot-Optional
17	<a href="#">660658</a>		Clamp, Motor Mounting 343481 685441
18	8530603	<a href="#">8533643</a>	Cabinet
19	<a href="#">98234</a>		Clip, U-Bend
20	<a href="#">18776</a>		Lock, Front Top
21	3403447	<a href="#">279854</a>	Panel
22	8318272	<a href="#">W10465748</a>	Burner-Gas
23	685203	<a href="#">279220</a>	Clip
24	<a href="#">3389441</a>		Door Catch Assembly
25	<a href="#">3405246</a>		Seal, Door Push-To-Start
26	<a href="#">348780</a>		Base, Motor
27	342055	<a href="#">488627</a>	Screw
28	3405514	<a href="#">W10362431</a>	Hinge And Pin Assembly
29	8066206	<a href="#">279827</a>	Motor-Drive
30	<a href="#">8066184</a>		Pulley, Motor
31	<a href="#">3400500</a>		Bolt, 3405245 5/16-18 X 3/4
32	W10131364	<a href="#">341241</a>	Belt
33	<a href="#">3403431</a>		Strike, Panel
34	<a href="#">691366</a>		Idler And Pulley Assembly
35	<a href="#">3402341</a>		Door, Inner
36	<a href="#">3402335</a>		Door, Front
37	<a href="#">8565970</a>		Handle, Door
38	<a href="#">3406129</a>		Seal And Bearing Assembly
39	<a href="#">3394975</a>		Plug, Front Panel
40	344020	<a href="#">3401402</a>	Cord, Power
41	<a href="#">3394083</a>		Clip, Front Panel
42	<a href="#">8066217</a>		Hinge, Top

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>