


# Maytag MGD5870TW1 01 - TOP AND CONSOLE PARTS



## TOP AND CONSOLE PARTS

For Model: MGD5870TW1  
(White)

29" GAS DRYER



9-07 Litho in U.S.A.(LT)

1

Part No. W10164768 Rev. A

Maytag Residential Maytag MGD5870TW1 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10089171		Not Available	Sheet, Cycle Feature
"	W10088775		Not Available	Use & Care Guide
"	8578889		Not Available	Wiring Diagram
2	<a href="#">W10113080</a>			Wire, Jumper
3	<a href="#">694419</a>			Mini-Buzzer
4	<a href="#">W10112603</a>			Seal, Harness
5	8533971	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
6	<a href="#">W10112577</a>			Panel, Rear Console
7	<a href="#">3405155</a>			Switch, Temperature
8	<a href="#">W10117655</a>			Switch, Push-To-Start
9	<a href="#">8566184</a>			Timer Assembly
10	<a href="#">8565972</a>			Screen, Lint
11	<a href="#">8536939</a>			Clip, Knob
12	359625	<a href="#">487240</a>		Screw, For Mtg. Service Capacitor
13	688082	<a href="#">487240</a>		Screw, For Mtg. Service

13	<a href="#">000903</a>	<a href="#">407440</a>	Capacitor
14	<a href="#">W10112599</a>		Top
15	237446	<a href="#">487596</a>	Washer
16	<a href="#">W10110996</a>		Harness, Wiring
17	<a href="#">717252</a>		Receptacle, Terminal
18	<a href="#">W10112578</a>		Harness, Bracket
19	<a href="#">3394427</a>		Clip-Harness
20	337686	Not Available	SCREW, 8-18 X .500
21	<a href="#">693995</a>		Screw, Hex Head
22	<a href="#">8558178</a>		Control, Electronic
23	<a href="#">3391885</a>		Connector, Edge
24	<a href="#">3397269</a>		Connector, Timer
25	<a href="#">3401144</a>		Connector
26	<a href="#">3403499</a>		Connector, 2-Postion
27	<a href="#">3403498</a>		Connector, 3-Position
28	<a href="#">3405156</a>		Switch, Rotary
29	<a href="#">3395683</a>		Receptacle, Multi-Terminal
30	<a href="#">3936144</a>		Do-It-Yourself Repair Manuals
31	<a href="#">94614</a>		Terminal
32	<a href="#">W10110035</a>		Knob
33	<a href="#">3347243</a>		Block, Disconnect
34	<a href="#">W10110036</a>		Knob
35	W10086717	<a href="#">W10142695</a>	Console
36	<a href="#">8312709</a>		Clip-Console
37	W10112569	<a href="#">W10203949</a>	Medallion

