


# Maytag MGD7000XG1 01 - TOP AND CONSOLE PARTS

**MAYTAG**

**TOP AND CONSOLE PARTS**  
 For Models: MGD7000XW1, MGD7000XR1, MGD7000XG1  
 (White) (Red) (Cosmetallic)

29" GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

7-11 Printed in U.S.A. (LT) (psw)

1

Part No. W10431370 Rev. A

Maytag [Residential Maytag MGD7000XG1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10312954		Not Available	USE & CARE GUIDE
"	W10423115		Not Available	INSTALLATION, INSTRUCTION
"	W10316958		Not Available	TECH SHEET
2	<a href="#">W10208383</a>			Top
"	<a href="#">W10337792</a>			Top
"	<a href="#">W10301057</a>			Top
3	<a href="#">W10355891</a>			Harness, Main
4	<a href="#">W10350669</a>			Panel, Console
"	<a href="#">W10350671</a>			Panel, Console
"	W10350673	<a href="#">W10388467</a>		Console
5	<a href="#">W10317570</a>			Water Channel
6	<a href="#">W10208198</a>			Bracket, Console
7	<a href="#">W10309986</a>			Cable, Jumper
8	<a href="#">W10309987</a>			Cable, Jumper
9	<a href="#">W10267833</a>			Cable, Led User-Interface
10	<a href="#">W10317566</a>			Spring, Clip Water Channel

