


Maytag MGD9600SQ0 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Model: MGD9600SQ0
(White)

Gas Dryer



IMPORTANT: All Part Numbers Listed Are Whirlpool Numbers. Source Parts Through Whirlpool.

9-06 Printed in U.S.A. (LT)

1

Part No. 8181472 Rev.A.

Maytag [Residential Maytag MGD9600SQ0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10099060		Not Available	Use & Care Guide
"	W10049500		Not Available	Tech Sheet
"	W10099080		Not Available	Guide, Quick Start
2	3980634	W10117263		Top
3	8299950			Harness, Main
4	W10100388	W10100389		Panel-Control
5	3394427			Clip-Harness
6	8519271			Bracket, Console
7	353424			Plug, Terminal
8	94614			Terminal
9	3936144			Do-It-Yourself Repair Manuals
10	94613	596797		Terminal
11	3390647	488729		Screw
12	488886	488787		Screw
13	8542690			Bezel, Cycle
14	3936150			Connector, 7-Circuit

15	3395683	Receptacle, Multi-Terminal
16	8281225	Screw, 8-18 X 1/2
17	2203186	Connector, 5-Circuit
18	8580139	Knob, Assembly
19	8558455	User Interface
20	8562598	Endcap
21	8562597	Endcap
22	8542682	Light Indicator
23	8542683	Light Indicator
24	8542691	Lens, Display
25	8542684	Light Indicator
26	8542685	Light Indicator
28	8542717	Shaft, Cycle Selector
29	8542716	Bearing, Knob
30	8542715	Spring, Knob
31	8580140	Pushbutton,)
32	W10100390	Pushbutton,
33	8562604	Pushbutton,
34	8562605	Pushbutton,
35	8579994	Pushbutton,)

