


Maytag MGD9700SQ0 02 - CABINET PARTS



8181445

3

Maytag [Residential Maytag MGD9700SQ0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8317340			Cover, Terminal Block
2	3390814	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	8533974	4331106		Screw, No.10-32 X 7/16
4	W10139003	W10117273		Panel
"	W10139010	W10117283		Panel
5	3394881	279782		Switch-Lid
6	8521959	W10121663		Dryer Rack
7	W10138989	W10117272		Panel
"	W10138996	W10117282		Panel
8	3392100	49621		Feet-Leveling
"	279810			Foot-Optional
9	660658			Clamp, Motor Mounting 343481 685441
10	3387374			Spring, Idler
11	3389420			Retainer-Idler 1/4-20 X 1/16
12	697750	W10470674		Dryer Exhaust Kit

"	3388309	W10470674	Dryer Exhaust Kit
13	3388672	279640	Pulley-ldr
14	3978776		Bracket, Gas Pipe Switch
15	8066120		Lever, Door Switch
16	W10167612		Wire, Broken Belt Switch
17	W10128772	8564134	Board, Sound Dampening
18	W10121334		Washer, Thrust
19	W10128087	W10318609	Switch, Assembly Door
20	690997		Washer, Thrust
21	8066115	3394331	Plate Cover
22	8529053		Ramp, Door Door Switch
23	8521961		Support, Dry Rack
24	693995		Screw, Hex Head
25	8521957	W10121663	Dryer Rack
26	343641	681414	Screw, 10AB X 1/2
27	8538263	279787	Motor-Drve
28	3398948		Wire, Jumper
29	8578220		Pulley, Motor
30	3387610	661570	Belt
31	8529757		Bracket, Burner
32	3387118		Bracket, Motor
33	3401401	3401402	Cord, Power
34	49026		4" - 90° Elbow
35	692400		Nut, Push-In
36	8563747		Exhaust Pipe Medium Pipe
37	8563750		Exhaust Pipe
38	8563749		Exhaust Pipe
39	3388674	W10118756	Idler Bracket
40	W10133207	280036	Panel-Rear
41	3400826		Screw, 8-18 X 3/4
42	98129		Screw, 6-20 X 1 1/16
43	3390647	488729	Screw
44	3387242		Seal, Front Panel
45	3393008	308685	Side Trim)
46	8519459		Clip, Toe Panel
47	8519207		Base, Cabinet
48	8565907	280101	Panel
"	8579973	Not Available	Front Panel (Includes Illus. 44) (Black)
49	696144	279570	Latch
50	8299929		Harness, Digital Interface
51	8519273	W10119274	Bracket, Control
52	8546219		Control Board
53	W10116271	W10246269	Panel, Toe
"	W10116273		Toe Panel
54	62825		Clip-S Type Control Board
"	BLANK	Not Available	OPTIONAL PARTS (NOT INCLUDED)
55	279818	W10470674	Dryer Exhaust Kit
"	279820	W10470674	Dryer Exhaust Kit