


Maytag MGDB850WR0 02 - CABINET PARTS

CABINET PARTS

For Models: MGDB850WQ0 (White), MGDB850WL0 (Silver), MGDB850WB0 (Black), MGDB850WR0 (Red)



W10284352

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3

Maytag [Residential Maytag MGDB850WR0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10007520			Clip, Ground
2	8544753			Bracket, Burner
3	3390631			Screw, 10-16 X 3/8
4	8558833			Plate, Cover Terminal Block
5	8564012			Switch, Assembly
6	344020	3401402		Cord, Power
7	W10223154			Cabinet
"	W10283292			Cabinet
"	W10223155			Cabinet
"	W10283291			Cabinet
8	3392100	49621		Feet-Leveling
NI	279810			Foot-Optional
9	660658			Clamp, Motor Mounting 343481 685441
10	3387374			Spring, Idler
11	3389420			Retainer-Idler 1/4-20 X 1/16
12	W10123956			Dampening Panel

13	8547160		Pulley Assembly
14	W10201446		Bracket-Gas Pipe
15	W10224768		Seal, Foam Spill Guard
16	8539892		Wire-Motor To Belt Switch
17	W10323735		Badge
18	W10167613		Wire, Belt Switch
19	3394083		Clip, Front Panel
20	8564010		Assembly, Switch And Actuator
21	8579717		Assembly, Hinge
"	W10252472		Hinge Assembly
"	W10111912		Assembly, Hinge
"	W10252473		Hinge Assembly
22	W10111858		Glass,
23	8564011		Bracket-Switch
24	3393008	308685	Side Trim)
25	W10111880		Bezel, Door
26	3393657		Restrainer, Belt
27	W10136932		Motor, Assembly 60 Hz
28	W10140148		Panel, Rear
29	W10139247		Pulley, Blower
30	W10136934		Belt, Drive
31	8578560		Hole, Plug
32	8547158		Bracket, Motor
33	W10111905		Assembly, Door Catch
34	W10002600		Screw, 6-20 X 1 1/4
35	8568303		Locator, Snap Down
36	W10215725		Cover, Door Switch
37	3400805		Screw, 8-18 X 3/64
38	W10144494		Plug-Hole
39	W10221653	W10239307	Seal-Door
40	342055	488627	Screw
41	W10201785		Door Switch Assembly
42	W10111857		Glass, Inner Door
43	8576625		Lock, Front Top
44	W10044490		Seal, Front Panel
45	8564457		Plug, Front Panel
"	W10249704		Plug, Front Panel
"	8573008		Plug, Front Panel
"	W10256411		Plug, Front Panel
46	238088	8066217	Hinge, Top
47	W10111878		Door, Inner
"	W10111900		Door, Inner
"	W10111910		Door, Inner
"	W10252475		Door, Inner
48	W10316529		Foam-Seal Cabinet
49	W10111875		Door, Outer
"	W10252478		Door, Outer
"	W10111909		Door, Outer
"	W10252479		Door, Outer
50	W10136930		Pulley,
51	W10235342	W10307829	Panel
"	W10283296		Panel, Front

"	W10235343		Panel, Front
"	W10283299	Not Available	PANEL, FRONT (RED)
52	W10111906	W10295405	Strike
53	W10111888		Plug, Strike
54	W10111859		Gasket, Inner Door
55	W10183818		Cover, Gas Valve

