


# Maytag MGDB850YW1 02 - CABINET PARTS



Maytag [Residential Maytag MGDB850YW1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10007520</a>			Clip, Ground
2	<a href="#">8544753</a>			Bracket, Burner
3	<a href="#">3390631</a>			Screw, 10-16 X 3/8
4	<a href="#">8558833</a>			Plate, Cover Terminal Block
5	<a href="#">W10314253</a>			Switch, Assembly Broken Belt
6	<a href="#">W10440460</a>			Cord, Power
7	<a href="#">W10223154</a>			Cabinet
"	<a href="#">W10338830</a>			Cabinet
8	<a href="#">W10363894</a>			Foot, Dryer
9	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
10	<a href="#">3387374</a>			Spring, Idler
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16
12	<a href="#">W10363887</a>			Riser-Full
13	<a href="#">8547160</a>			Pulley Assembly
14	<a href="#">W10201446</a>			Bracket-Gas Pipe
16	W10111906	<a href="#">W10295405</a>		Strike

17	<a href="#">W10323735</a>		Badge
19	<a href="#">3394083</a>		Clip, Front Panel
20	<a href="#">W10136930</a>		Pulley,
21	<a href="#">W10252472</a>		Hinge Assembly
22	<a href="#">w10394552</a>		Window-Outer
23	<a href="#">W10111888</a>		Plug, Strike
24	<a href="#">W10224768</a>		Seal, Foam Spill Guard
25	<a href="#">W10304170</a>		Bezel, Door Clip
26	<a href="#">3393657</a>		Restrainer, Belt
27	<a href="#">W10136932</a>		Motor, Assembly 60 Hz
28	<a href="#">W10140148</a>		Panel, Rear
29	<a href="#">W10139247</a>		Pulley, Blower
30	<a href="#">W10136934</a>		Belt, Drive
32	<a href="#">8547158</a>		Bracket, Motor
33	<a href="#">W10111905</a>		Assembly, Door Catch
34	<a href="#">W10111859</a>		Gasket, Inner Door
35	<a href="#">8568303</a>		Locator, Snap Down
36	<a href="#">W10215725</a>		Cover, Door Switch
37	<a href="#">3400805</a>		Screw, 8-18 X 3/64
38	<a href="#">W10144494</a>		Plug-Hole
39	W10221653	<a href="#">W10239307</a>	Seal-Door
40	342055	<a href="#">488627</a>	Screw
41	<a href="#">W10201785</a>		Door Switch Assembly
42	<a href="#">W10111857</a>		Glass, Inner Door
43	<a href="#">8576625</a>		Lock, Front Top
44	<a href="#">W10044490</a>		Seal, Front Panel
45	<a href="#">8564457</a>		Plug, Front Panel
"	<a href="#">W10301055</a>		Plug, Front Panel
46	238088	<a href="#">8066217</a>	Hinge, Top
47	<a href="#">W10111878</a>		Door, Inner
"	<a href="#">W10304172</a>		Door, Inner
48	<a href="#">W10316529</a>		Foam-Seal Cabinet
49	<a href="#">W10252478</a>		Door, Outer
"	<a href="#">W10344649</a>		Door, Outer
50	W10235342	<a href="#">W10307829</a>	Panel
"	<a href="#">W10252457</a>		Panel, Front

