


Maytag MGDB950YG2 02 - CABINET PARTS



Maytag [Residential Maytag MGDB950YG2 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	98234			Clip, U-Bend
2	8544753			Bracket, Burner
3	3390631			Screw, 10-16 X 3/8
4	8558833			Plate, Cover Terminal Block
5	W10314253			Switch, Assembly Broken Belt
6	W10440460			Cord, Power
7	W10183827	W10223154		Cabinet
"	W10304162		Not Available	CABINET (INCLUDES ITEM 51) (COSMETALLIC)
8	W10363894			Foot, Dryer
NI	279810			Foot-Optional
9	660658			Clamp, Motor Mounting 343481 685441
10	3387374			Spring, Idler
11	3389420			Retainer-Idler 1/4-20 X 1/16
12	W10363887			Riser-Full
13	8547160			Pulley Assembly

14	W10201446		Bracket-Gas Pipe
17	W10323735		Badge
19	3394083		Clip, Front Panel
21	W10249708		Hinge, Assembly
"	W10463337		Assembly, Hinge
22	W10369542		Window, Outer
25	W10304170		Bezel, Door Clip
26	3393657		Restrainer, Belt
27	W10460374		Motor, Assembly 60 Hz
28	W10140148		Panel, Rear
29	W10139247		Pulley, Blower
30	W10136934		Belt, Drive
31	W10123956		Dampening Panel
32	8547158		Bracket, Motor
33	W10111905		Assembly, Door Catch
34	3390631		Screw, 10-16 X 3/8
35	8568303		Locator, Snap Down
36	W10215725		Cover, Door Switch
37	3400805		Screw, 8-18 X 3/64
38	W10144494		Plug-Hole
39	W10221653	W10239307	Seal-Door
40	342055	488627	Screw
41	W10350909		Door Switch Assembly
42	W10111857		Glass, Inner Door
43	8576625		Lock, Front Top
44	W10044490		Seal, Front Panel
45	8564457		Plug, Front Panel
"	W10301055		Plug, Front Panel
46	238088	8066217	Hinge, Top
47	W10111878		Door, Inner
"	W10304172		Door, Inner
48	W10316529		Foam-Seal Cabinet
49	W10252478		Door, Outer
"	W10344649		Door, Outer
50	W10136930		Pulley,
51	W10463262		Front Panel And Foam Seal Assembly
"	W10463264		Panel, Front
52	W10111906	W10295405	Strike
53	W10111888		Plug, Strike
54	W10111859		Gasket, Inner Door
56	3393008	308685	Side Trim)