


Maytag MGDC700VW0 02 - CABINET PARTS



W10223214

3

Maytag [Residential Maytag MGDC700VW0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	697773	3395530		Screw
2	8529757			Bracket, Burner
3	3390647	488729		Screw
4	3394331			Plate Cover
5	3394881	279782		Switch-Lid
6	344020	3401402		Cord, Power
7	8310656			Cabinet
"	W10212721			Cabinet
8	3392100	49621		Feet-Leveling
NI	279810			Foot-Optional
9	660658			Clamp, Motor Mounting 343481 685441
10	3387374			Spring, Idler
11	3389420			Retainer-Idler 1/4-20 X 1/16
12	49252			Plug, Multivent
13	3388672	279640		Pulley-ldr
14	343641	681414		Screw, 10AB X 1/2

15	8533974	4331106	Screw, No.10-32 X 7/16
16	3398948		Wire, Jumper
17	8563747		Exhaust Pipe Medium Pipe
18	690997		Washer, Thrust
19	W10291934		Clip
20	W10121334		Washer, Thrust
21	3389247		Hinge And Pin Assembly
22	3390902		Clip, Door Hinge
23	8066120		Lever, Door Switch
24	W10167612		Wire, Broken Belt Switch
25	49026		4" - 90° Elbow
26	W10116360		Handle, Door
"	W10212775		Handle, Door
27	8538263	279787	Motor-Drive
28	8563750		Exhaust Pipe
29	8578220		Pulley, Motor
30	W10112954		Belt, Drive
31	693995		Screw, Hex Head
32	3387118		Bracket, Motor
33	8563749		Exhaust Pipe
34	8281212	W10080800	Screw, 8-18 X 3/8
35	98129		Screw, 6-20 X 1 1/16
36	693152		Bumper, Console
37	3390735		Seal, Door
38	3392538	279570	Latch
39	3388674	W10118756	Idler Bracket
40	3357011	308685	Side Trim)
41	3406107		Door Switch Assembly
42	697215	3406797	Toe Panel
"	W10212779		Toe, Panel
43	3387242		Seal, Front Panel
44	3388229		Retainer, Toe Panel
45	3392563	280083	Door-Rear
46	342055	488627	Screw
47	3387872		Door, Front
"	W10207719		Door, Front
48	W10193554	W10231550	Panel
"	W10212762	W10240837	Panel
49	696144	279570	Latch
50	3389249		Nut, Inner Door
51	W10191265		Plug, Hinge Screw Front Panel
52	342055	488627	Screw
NI	W10331132		Dryer Exhaust Kit