


Maytag MGDX700AG0 01 - TOP AND CONSOLE PARTS



4-12 Printed in U.S.A. (BMN) (psw) 1 Part No. W10502917 Rev. A

Maytag Residential Maytag MGDX700AG0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10096989		Not Available	GUIDE, USE & CARE
"	W10115228		Not Available	INSTRUCTIONS, INSTALLATION
"	W10417013		Not Available	TECH SHEET
2	W10280079			Seal, Console
3	8536939			Clip, Knob
4	W10326923			Spacer, Knob
5	W10287253			Harness, Wiring
6	W10246218			Top
7	W10459653			Console Assembly
8	W10251384			Knob, Control
9	W10305134			Bezel, Cycle Trim
10	3196172			Screw, 6-19 X 3/8
11	8312709			Clip-Console
12	W10285494			Cable, User Interface
13	W10272644			User Interface Assembly
14	W10219342			Screw, Baffle Mounting

15	W10274524		Tensioner, Facia
16	W10323735		Badge
17	W10096969		Panel, Rear Console
18	W10279552		Plug-Upper Rear Panel
19	W10323092		Seal, User Interface
20	W10338363		Cover, Terminal Block
21	3390814	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
22	W10271580		Bracket, Motor Control
23	W10214009		Control, Electronic
24	342055	488627	Screw
25	W10298336		8-18 Nch, U-Type NUT

the laundry company[®]

the laundry company[®]

the laundry company[®]