


# Maytag MGD700XW0 01 - TOP AND CONSOLE PARTS



Maytag Residential Maytag MGD700XW0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10096989		Not Available	GUIDE, USE & CARE
"	W10115228		Not Available	INSTRUCTIONS, INSTALLATION
"	W10097036		Not Available	TECH SHEET
2	<a href="#">W10280079</a>			Seal, Console
3	<a href="#">8536939</a>			Clip, Knob
4	<a href="#">W10326923</a>			Spacer, Knob
5	<a href="#">W10287253</a>			Harness, Wiring
6	<a href="#">W10268730</a>			Top
"	<a href="#">W10268731</a>			Top
7	<a href="#">W10293248</a>			Console Assembly
"	<a href="#">W10293249</a>			Console Assembly
8	<a href="#">W10251381</a>			Knob, Control
"	<a href="#">W10251384</a>			Knob, Control
9	<a href="#">W10305134</a>			Bezel, Cycle Trim
10	<a href="#">3196172</a>			Screw, 6-19 X 3/8
11	<a href="#">8312709</a>			Clip-Console

12	<a href="#">W10285494</a>		Cable, User Interface
13	<a href="#">W10272644</a>		User Interface Assembly
14	<a href="#">W10219342</a>		Screw, Baffle Mounting
15	<a href="#">W10274524</a>		Tensioner, Facia
16	<a href="#">W10323735</a>		Badge
17	<a href="#">W10096969</a>		Panel, Rear Console
18	<a href="#">W10279552</a>		Plug-Upper Rear Panel
19	337686	Not Available	SCREW, 8-18 X .500
20	<a href="#">W10338363</a>		Cover, Terminal Block
21	3390814	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
22	<a href="#">W10271580</a>		Bracket, Motor Control
23	W10296532	<a href="#">W10214009</a>	Control, Electronic
24	342055	<a href="#">488627</a>	Screw

