


Maytag MGT3800XW1 01 - WASHER/DRYER CONTROL PANEL PARTS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

1-12 Litho in U.S.A. (JLP)(bay)

1

Part No W10480172 Rev. A

Maytag [Residential Maytag MGT3800XW1 Washer/Dryer Parts](#) Parts Diagram 01 - WASHER/DRYER CONTROL
PANEL PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10356101		Not Available	INSTALLATION INSTRUCTIONS
"	W10343072		Not Available	USE & CARE GUIDE
"	W10364012		Not Available	WIRING DIAGRAM
"	W10389461		Not Available	ENERGY GUIDE
2	3390688			Spacer- Foam Pad
3	8528583			Bracket, Control
4	W10124193			Timer, Washer
5	W10339548			Panel, Control
6	W10112571			Dial,
7	W10110033			Knob, Timer
8	W10110035			Knob
9	8536939			Clip, Knob
10	W10134186			Clip, Harness
11	W10110036			Knob
12	3400808			Screw. Mounting

13	W10415756	W10510877	WL Switch
14	W10114118		Switch, Temperature
15	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
16	W10117655		Switch, Push-To-Start
17	8521965		Gasket, Console
18	694419		Mini-Buzzer
19	W10113816		Timer, Dryer
20	8558178		Control, Electronic
21	3389453		Bracket, Hinge
22	3389456		End Cap
23	W10371543		Harness - Dryer
24	697776	4331106	Screw, No.10-32 X 7/16
25	W10210799		Clip, Harness
26	3390604		Clamp, Harness
27	3389464		End Cap
28	W10334336		Cable Tie
29	W10368079		Hose, Pressure Switch
30	W10400880	W10510877	WL Switch

