


# Maytag MGT3800XW1 02 - DRYER FRONT PANEL AND DOOR PARTS

## DRYER FRONT PANEL AND DOOR PARTS

For Model: MGT3800XW1  
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

2

W10480172

Maytag [Residential Maytag MGT3800XW1 Washer/Dryer Parts](#) Parts Diagram 02 - DRYER FRONT PANEL AND DOOR PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3389249</a>			Nut, Inner Door
2	<a href="#">3391902</a>			Switch, Door
3	<a href="#">98234</a>			Clip, U-Bend
4	3392547	<a href="#">279718</a>		Panel
5	<a href="#">3390735</a>			Seal, Door
6	<a href="#">W10323061</a>			Door, Rear
7	<a href="#">W10322546</a>			Door, Front
8	<a href="#">3388229</a>			Retainer, Toe Panel
9	<a href="#">3387242</a>			Seal, Front Panel
10	<a href="#">W10134186</a>			Clip, Harness
11	696144	<a href="#">279570</a>		Latch
12	697773	<a href="#">3395530</a>		Screw
13	3393008	<a href="#">308685</a>		Side Trim )
14	3392538	<a href="#">279570</a>		Latch
15	<a href="#">W10116360</a>			Handle, Door
16	<a href="#">3390902</a>			Clip, Door Hinge

17 [3388958](#)

Panel, Toe

18 342055

[488627](#)

Screw

19 [3389247](#)

Hinge And Pin Assembly

