


Maytag MHG15PDAXW 01 - CABINET-FRONT (LOWER)



Maytag Residential Maytag MHG15PDAXW Dryer Parts Parts Diagram 01 - CABINET-FRONT (LOWER)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	33002005	33002963		Support, Weld Assembly
"	NLA		Not Available	(ALM)
002	22001883	214354		Screw, Top Cover To Cabnt.
003	NLA		Not Available	BRACKET, TERMINAL BLOCK---NA
004	22001995			Screw Note: Screw, Tumbler Front And Shroud
005	22001502			Fastener, U-NUt
006	NLA		Not Available	CABINET (WHT)
007	22002049			Clip Note: Clip, Front Panel
008	Y313561			Screw---NA
"	314627			Bracket, Relays
"	Y310632	1163839		Screw
009	206824	W10133335		Relay, Motor
"	Y251119	3177991		Screw
010	213007			Xfor Cabinet See Cabinet, Back

011	22002259	22002767	Brace, Cross
012	22001995		Screw Note: Screw, Tumbler Front And Shroud
013	Y310376		Clip, Door Switch Harness
014	22001995		Screw Note: Screw, Tumbler Front And Shroud
015	33002009		Bracket, Corner
"	33002010	33002473	Bracket, Corner
016	33002011		Cover, Access
"	33002012		Cover, Access
017	33002013		Fastener Clip, Access Cover
018	22001995		Screw Note: Screw, Tumbler Front And Shroud
019	33002064		Wire Harness, Main
020	33001989		Retainer, Vault Switch

the laundry company[®]

the laundry company[®]

the laundry company[®]