


# Maytag MHW7000XR2 01 - TOP AND CABINET PARTS

**MAYTAG**

**TOP AND CABINET PARTS**  
 For Models: MHW7000XW2, MHW7000XR2, MHW7000XG2  
 (White) (Red) (Cosmetallic)

AUTOMATIC  
 WASHER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

4-11 Printed in U.S.A. (MP)(day)

1

Part No. W10413847 Rev. A

Maytag Residential Maytag MHW7000XR2 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10254447		Not Available	INSTALLATION INSTRUCTIONS (ENGLISH/FRENCH)
"	W10254448		Not Available	INSTALLATION INSTRUCTIONS (SPANISH)
"	W10254495		Not Available	USE & CARE GUIDE (ENGLISH/FRENCH)
"	W10254496		Not Available	USE & CARE GUIDE (SPANISH)
"	W10254474		Not Available	TECH SHEET
"	W10254490		Not Available	ENERGY GUIDE
2	<a href="#">W10208373</a>			Top
"	<a href="#">W10337799</a>			Top
"	<a href="#">W10304145</a>			Top
3	W10237487	<a href="#">W10441110</a>		Cabinet
"	<a href="#">W10337793</a>			Cabinet
"	<a href="#">W10301048</a>			Cabinet
4	<a href="#">W10208182</a>			Panel, Front

"	<a href="#">W10337797</a>		Panel, Front
"	<a href="#">W10301079</a>		Panel, Front
5	<a href="#">W10237503</a>		Retainer, Bellow To Front Panel
6	8183197	<a href="#">8183270</a>	Lock, Door
7	8540282	<a href="#">8181661</a>	Screw, Actuator
8	<a href="#">8540329</a>		Screw, 8-18 X 7/16
9	<a href="#">W10339879</a>		Tie, Cable
10	<a href="#">W10339734</a>		Harness, Wiring
11	<a href="#">W10374126</a>		Motor Control Unit
12	W10271590	<a href="#">W10498442</a>	Bolt
13	<a href="#">W10237498</a>		Brace, Transport
14	<a href="#">W10237492</a>		Panel, Rear
15	<a href="#">W10142290</a>		Screw, 8-18 X 5/16
16	<a href="#">W10354386</a>		Brace, Rear
17	<a href="#">W10305097</a>		Screw, M4.1-1.8 X 57
18	<a href="#">W10181028</a>		Clip, Pressure Switch Hose
19	<a href="#">W10326464</a>		Filter, Interference
20	<a href="#">W10312527</a>		Switch, Analog Pressure Sensor
21	<a href="#">W10251962</a>		Hose, Pressure Switch
22	<a href="#">W10245452</a>		Retainer, Spring
23	<a href="#">W10237490</a>		Brace, Top
24	<a href="#">356138</a>		Clamp, Hose
25	<a href="#">W10280024</a>		U-Bend, Drain Hose
26	<a href="#">W10267638</a>		Hose, Drain
27	W10326100	<a href="#">W10434975</a>	Cord, Power
28	<a href="#">3351614</a>		Screw, Gearcase Cover Mounting
29	<a href="#">W10275820</a>		Cover, Power Cord- Transport
30	8182700	<a href="#">8540268</a>	Cover, Transport
31	<a href="#">W10208380</a>		Screw, Bush Assembly
32	<a href="#">W10304004</a>		Cover, Power Cord
33	W10194208	<a href="#">89503</a>	Hose-Inlet
"	8571378	<a href="#">89503</a>	Hose-Inlet
34	W10242307	<a href="#">16123</a>	Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
35	<a href="#">W10298211</a>		Stud Assembly, Front Panel
36	<a href="#">W10323182</a>		Spacer, Front Panel
37	<a href="#">W10001130</a>		Foot, Leveling
38	<a href="#">3359452</a>		Nut, Lock

*the laundry company*<sup>®</sup>