


Maytag MHWE300VW00 02 - DOOR AND LATCH PARTS

DOOR AND LATCH PARTS

For Models: MHWE300VW00, MHWE300VF00
(White) (Red Metallic)



W10208574

3

Maytag [Residential Maytag MHWE300VW00 Washer Parts](#) Parts Diagram 02 - DOOR AND LATCH PARTS
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|---------------------------|--------|-------------------------------|
| 1 | 8182210 | | | Clamp, Bellow |
| 2 | W10003800 | 8182119 | | Bellow |
| 3 | 8540772 | W10253483 | | Lock, Door |
| 4 | W10003490 | 8182211 | | Clamp, Bellow To Front Panel |
| 5 | 8540725 | | | Screw |
| 6 | W10003390 | W10217552 | | Hook, Door |
| 7 | 8540513 | 8182214 | | Screw |
| 8 | 8540282 | 8181661 | | Screw, Actuator |
| 9 | 8540284 | 8181660 | | Screw |
| 10 | W10003370 | 8183195 | | Frame, Door Back Support |
| 11 | W10003430 | W10128586 | | Clamp, Glass Support |
| 12 | W10135912 | 8181655 | | Glass, Door |
| 13 | W10200695 | 8183202 | | Hinge, Door |
| 14 | W10015090 | 489442 | | Screw 3 2217757 Roller, Front |
| 15 | W10003440 | W10295703 | | Clamp, Glass |
| 16 | W10005220 | 8183256 | | Frame, Door Front Support |

17 [W10153278](#)

Screen, Door

18 [W10193430](#)

Trim Ring, Outer Door

19 W10153281

[W10121607](#)

Pad, Door Handle

