


## Maytag MLE2000AZW 06 - CONTROL PANEL



Maytag [Residential Maytag MLE2000AZW Stacked Washer and Dryer Parts](#) Parts Diagram 06 - CONTROL PANEL  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">22002460</a>			Facia
2	<a href="#">33002132</a>			Knob, Timer
3	<a href="#">22001664</a>			Timer Knob Insert/Cap
4	<a href="#">22002461</a>			Knob, Timer
5	<a href="#">22002514</a>			Panel, Control
"	<a href="#">22002063</a>			Screw No.8-18AB Wafer Head
6	22001215	<a href="#">7730P011-60</a>		Lens, Indicator Light
7	<a href="#">33002072</a>			Panel, Access
"	<a href="#">33002004</a>			Clip, Fastener
"	<a href="#">22002063</a>			Screw No.8-18AB Wafer Head
8	<a href="#">33001980</a>			Fastener, Access Panel
9	<a href="#">33002109</a>			Timer
"	61001885	<a href="#">489399</a>		Screw, 8-32 X 5/16
"	<a href="#">33002677</a>			Timer, Electronic Dry
10	<a href="#">33001977</a>			Fastener, Control Panel
11	<a href="#">33001212</a>			Board, Control-Moisture Sensor

"	315317	<a href="#">488234</a>	Screw 8-32 X 1/4
12	22002517	<a href="#">489355</a>	Screw, 8 X 1/2
"	315471	<a href="#">22003298</a>	Retainer, Wire
"	<a href="#">22002515</a>		Channel, Switch Mounting
13	61001885	<a href="#">489399</a>	Screw, 8-32 X 5/16
"	<a href="#">22002516</a>		Bracket, Washer Timer
14	<a href="#">22002452</a>		Timer
"	Y310632	<a href="#">1163839</a>	Screw
15	<a href="#">33002121</a>		Switch, Temperature
"	<a href="#">22001789</a>		Button, Switch
"	<a href="#">22001788</a>		Button, Switch
16	Y310632	<a href="#">1163839</a>	Screw
"	<a href="#">22002518</a>		Bracket, Pts Switch
17	<a href="#">22002006</a>		Clip, Unbalance Switch Harness
"	<a href="#">22003824</a>		Wire Harness, Lower/Household
"	<a href="#">2205143</a>		Harness, Wire
"	<a href="#">22003820</a>		Wire Harness / Hh / Unbalance
"	<a href="#">22004471</a>		Harness, Wire Unbalance
"	33001861	<a href="#">33001618</a>	Switch- PU
"	33002227	Not Available	WIRE HARNESS, MAIN (UPR)
"	<a href="#">22003014</a>		Harness, Main Wire
18	33002219	<a href="#">22002560</a>	Switch, Push To Start
19	<a href="#">22001788</a>		Button, Switch
"	<a href="#">22002453</a>		Switch, Water Temp
"	<a href="#">22001789</a>		Button, Switch
20	<a href="#">22002455</a>		Switch, Options
"	<a href="#">22001788</a>		Button, Switch
"	<a href="#">22001789</a>		Button, Switch
21	315317	<a href="#">488234</a>	Screw 8-32 X 1/4
"	<a href="#">33001848</a>		Signal, End Of Cycle
22	<a href="#">22002281</a>		Indicator Light
23	<a href="#">903115</a>		Lock Light
24	<a href="#">33002226</a>		Wire Harness, Main
25	<a href="#">22002524</a>		Connector
26	33002448	Not Available	MANUAL, USE & CARE
"	<a href="#">33002447</a>		Manual, Use And Care
"	2206686	Not Available	MANUAL, USE & CARE TRILINGUAL
"	2202493	Not Available	MANUAL, USE & CARE-TRILINGUAL
27	<a href="#">16009127</a>		Manual, Service-No Refund
28	33002235	Not Available	VIDEO, U & C (STACK)
29	33002229	Not Available	LABEL, ENERGY
31	<a href="#">22003858</a>		EMI Suppression Filter, 16a