


# Maytag MLG19PDBGW 17 - DOOR LATCH ASSY



Maytag [Residential Maytag MLG19PDBGW Dryer Parts](#) Parts Diagram 17 - DOOR LATCH ASSY  
 Click on the part number to view part

| Item | Original Part Number     | Replaced By            | Status | Part Description         |
|------|--------------------------|------------------------|--------|--------------------------|
| 001  | <a href="#">22002119</a> |                        |        | Motor, Wax               |
| 002  | <a href="#">22003718</a> |                        |        | Axle, Latch              |
| 003  | <a href="#">22003721</a> |                        |        | Spring, Axle / Latch     |
| 004  | <a href="#">22003715</a> |                        |        | Sliding Gear, Latch      |
| 005  | <a href="#">22003716</a> |                        |        | Rotating Gear, Latch     |
| 006  | <a href="#">22003717</a> |                        |        | Spring, Latch            |
| 007  | <a href="#">22001352</a> |                        |        | Screw, Check Switch      |
| 008  | <a href="#">22002165</a> |                        |        | Washer, Door Lock Switch |
| 009  | <a href="#">33002782</a> |                        |        | Switch, Door Lock        |
| 010  | <a href="#">22002158</a> |                        |        | Spring, Gear Return      |
| 011  | <a href="#">33002783</a> |                        |        | Holder, Switch           |
| 012  | <a href="#">22003719</a> |                        |        | Screw, Latch             |
| 013  | <a href="#">22003720</a> |                        |        | Nut, Latch               |
| 014  | 22002435                 | <a href="#">241877</a> |        | Screw                    |
| 015  | <a href="#">22002957</a> |                        |        | Cover, Latch Assembly    |
| 016  | <a href="#">33002784</a> |                        |        | Lock Clip, Door          |

|     |                          |               |                       |
|-----|--------------------------|---------------|-----------------------|
| 017 | <a href="#">22003055</a> |               | Ramp, Door Hoop       |
| 018 | <a href="#">33002785</a> |               | Switch, Door          |
| 019 | <a href="#">22002164</a> |               | Cable, Door           |
| 020 | NLA                      | Not Available | LATCH, ASSY. (EXPORT) |

