


Maytag MLG19PDDGW 15 - DOOR SHROUD & DOOR LATCH ASSEMBLY (WASH)



Maytag [Residential Maytag MLG19PDDGW Dryer Parts](#) Parts Diagram 15 - DOOR SHROUD & DOOR LATCH ASSEMBLY (WASH)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	33002209			Retainer, Fabric Softener
002	22002506			Shroud And Dispenser Hose
003	22001995			Screw Note: Screw, Tumbler Front And Shroud
004	22003908			Vapor Barrier
"	33002203			Clip, Hose
"	33002477			Support, Door Lock
005	22002014			Clip, Harness To Support
006	33001764			Cover, Hinge Hole
"	33001787			Screw, Hinge Note: Screw, Hinge Hole Cover
007	33002195			Grate, Overflow
"	33002196			Grate, Overflow
008	33002197			Cup, Bleach Dispenser
009	33002198			Cup, Fabric Softener Dispenser

010	33002199		Spout, Dispenser Fill
011	33002200		Cap, Bleach Dispenser
012	33002201		Cap, Fabric Softener
013	33002204		Screen, Bleach Cup
014	22003681	22003263	Screw, Sump Cap
"	33002205		Retainer, Bleach Cup
015	33002206		Fastener, J Type
016	205161	489503	Clamp
017	22003653		Retainer, Dispenser Hose
"	33002207		Hose, Bleach
018	22003653		Retainer, Dispenser Hose
"	33002208		Hose, Fabric Softener
019	22002119		Motor, Wax
020	22003718		Axle, Latch
021	22003721		Spring, Axle / Latch
022	22003715		Sliding Gear, Latch
023	22002164		Cable, Door
024	22003055		Ramp, Door Hoop
025	22003716		Rotating Gear, Latch
026	22003717		Spring, Latch
027	22002435	241877	Screw
028	22002957		Cover, Latch Assembly
029	22003720		Nut, Latch
030	22003719		Screw, Latch
031	33002783		Holder, Switch
032	22002158		Spring, Gear Return
033	22001352		Screw, Check Switch
034	33002782		Switch, Door Lock
035	22002165		Washer, Door Lock Switch
036	33002785		Switch, Door
037	33002784		Lock Clip, Door
038	22002484	Not Available	LABEL, BLEACH
"	22002485	Not Available	LABEL, FABRIC SOFTENER
"	22002486	Not Available	LABEL, LOADING INSTRUCTIONS
"	22002487	Not Available	LABEL, ADD DETERGENT

