


Maytag MLG19PDSAW 02 - CONTROL CENTER (DRYER)



Maytag Residential Maytag MLG19PDSAW Dryer Parts Parts Diagram 02 - CONTROL CENTER (DRYER)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y33001983			Box, Coin
002	Y33001986			Vault, Coin
003	33002683	694091		Trim, Side Right Hand
004	Y052740	62739		Nut, Lock
005	Y052734			Nut, Carrage Bolts And Bracket
006	312535			Washer, Vault Mounting Brk.
"	NLA		Not Available	WASHER, VAULT MOUNTING BRK.
007	314635			Chute, Coin
008	22002536			Switch, Sensor
"	33001989			Retainer, Vault Switch
009	NLA		Not Available	NUT, CAGE
010	22001810		Not Available	STRAP, MOUNTING
011	33001989			Retainer, Vault Switch
012	33001990			Bracket, Mounting Vault
013	33001991			Bolt, Carriage

014	216200		Face Plate Return Button
"	22001873	22004112	Coin Drop Greenwald Us.25
"	33002510		Plate, Cover
015	22001965		Optic Switch Assembly
"	314665		Screw, Switch Assembly
016	33001992		Bracket, Coin Drop Mount.
017	212707	3196385	Screw
"	910181		Lockwasher, Terminal Block

