


Maytag MLG23PDHWW 01 - CONTROL PANEL



Maytag [Residential Maytag MLG23PDHWW Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	33002836	33003007		Control Board
"	33003007			Control Board
"	912077			Locknut, Reader Harness
002	33001204			Stand-Off, Ccontrol Board
003	33002152	W10133277		Membrane Switch Assembly
004	33002863	W10131113		Push Button
005	33002150	W10133268		Cover, Display
006	33002155			Plate, Control Mounting
007	33002978			Panel, Front Straight -PD
008	22001965			Optic Switch Assembly
"	314665			Screw, Switch Assembly
009	33002117	208042		Switch, Sensor
010	33002977			Assembly, Coin Vault
011	22001810		Not Available	STRAP, MOUNTING
"	910181			Lockwasher, Terminal Block
012	33002974		Not Available	BRACKET,VAULT - PRIME

013	213750	W10133266	Cam-Lock
014	33001982		Bracket, Switch Mounting
015	2206815	33002980	Coin Box----NA
"	33002980		Coin Box----NA
016	22002349	W10116737	Lock
017	33002976		Facia, Comercial PD, D/D
018	33001991		Bolt, Carriage
019	33002644		Dual Faceplate Assembly
"	33002647		Single Faceplate Assembly
020	22003678	22004112	Coin Drop Greenwald Us.25
"	22004112		Coin Drop Greenwald Us.25
"	22004113	W10133245	Dual Coin Drop Assembly
"	22004114		Coin Drop Greenwald .25
"	33002646		Coin Drop-Canada
021	215506		Screw, Control Panel Overlay
022	Y052734		Nut, Carrage Bolts And Bracket
023	Y052721		Nut, Terminal Block Plate
024	33002051	Not Available	SCREW, FRONT PANEL
025	33002117	208042	Switch, Sensor
026	2206813		Lock Plate
"	33002981	2206813	Lock Plate
027	33002982		Washer, Spinning Security
028	2206814		Assembly, Security Plate
"	33002979	2206814	Assembly, Security Plate

