


Maytag MLG32PDBWW 01 - CONTROL DOOR ASSEMBLY



Maytag [Residential Maytag MLG32PDBWW Dryer Parts](#) Parts Diagram 01 - CONTROL DOOR ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A311576			Control Door, Lower
"	A816127	W10147147		435-Hinged
"	A881977	W10148541		White ADG-
"	A881978	W10148542		Beige ADG-
"	A882181	W10148627		Bisque ADG
002	A180224	180224		435 Control L
003	A160040	160040		Dp Control
004	A150201	150201		10-32 X 1
005	A117605	117605		1 4thk X 3
006	A150301	150301		8-18 X 7
007	A114075			LABEL, DISPLAY (MAYTAG)
"	A114524	114524		435ii 436
"	A114525	114542		Maytag Key
008	A881935	W10148529		435 Hanke

009	A125157	Not Available	SWITCH, OPTIC (HANKE)
"	A125171	125171	Hanke .25
010	A150002	150002	6-32 X 1
011	A311581	W10146816	Ad-436d BO
012	A114522	114522	Maytag 435
"	A114523	114540	Maytag Log
013	A801093	801093	436d Top C

