


Maytag MTW5620TQ1 03 - AGITATOR, BASKET AND TUB PARTS



Maytag [Residential Maytag MTW5620TQ1 Washer Parts](#) Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8565968			Dispenser, Fabric Softener
2	3354733	W10074580		Cap, Barrier
3	3348855	W10072840		Fabric Softener
4	358237			Screw And Washer
5	3949550			Washer
6	W10093672			Agitator
7	3363663	285811		Cam-Agitator
8	3366877	80040		Dog-Agitator
9	3363661			Bearing, Driven Cam
10	3349019			Auger, Agitator
11	3350389	285587		Washer
12	W10110020			Agitator
13	8528150	W10445870		Ring-Tub
14	3976308			Gasket, Tub Ring
15	3354845			Clip, Agitator
16	8543666			Washer, Agitator

17	8519788	387240	Ring, Balance
18	21366		Nut, Spanner
19	8526017	W10389329	Clothes Container, Assembly
20	2219077		Clip, Pressure Switch Hose
21	3347780	353244	Hose, Pressure Switch
22	389140		Tub Block, Basket Drive
23	63849		Strain Relief, Power Cord
24	383727		Gasket, Centerpodt

