


Maytag MTW5921TW0 03 - AGITATOR, BASKET AND TUB PARTS



Maytag Residential Maytag MTW5921TW0 Washer Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8565968			Dispenser, Fabric Softener
2	3354733	W10074580		Cap, Barrier
3	3348855	W10072840		Fabric Softener
4	358237			Screw And Washer
5	3949550			Washer
6	W10093672			Agitator
7	3363663	285811		Cam-Agitator
8	3366877	80040		Dog-Agitator
9	3363661			Bearing, Driven Cam
10	3349019			Auger, Agitator
11	3350389	285587		Washer
12	W10110020			Agitator
13	3954507	W10213410		Ring-Tub
14	3359585	3976308		Gasket, Tub Ring
15	3354845			Clip, Agitator
16	8543666			Washer, Agitator

17	W10106550	W10006326	Balance Ring
18	W10116603	W10116602	Nut, Spanner
19	8579546		Basket And Balance Ring
20	2219077		Clip, Pressure Switch Hose
21	3347780	353244	Hose, Pressure Switch
22	389140		Tub Block, Basket Drive
23	8283125		Tub
24	383727		Gasket, Centerpodt
25	8318246	W10213410	Ring-Tub
26	3948705		Hose, Bleach

