


# Maytag MUG15PDAWA 01 - CONTROL PANEL



Maytag [Residential Maytag MUG15PDAWA Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	33001974		Not Available	OVERLAY, CONTROL PANEL
002	<a href="#">215506</a>			Screw, Control Panel Overlay
003	<a href="#">33001209</a>			Cover, Display
004	33001975	<a href="#">22002457</a>		Panel- Con
"	33001976	<a href="#">33002377</a>		Panel, Control
"	<a href="#">33002003</a>			Fastener Clip, Control Panel
005	22002062	<a href="#">98006631</a>		Screw
"	910186	<a href="#">99002757</a>		Screw
006	<a href="#">215506</a>			Screw, Control Panel Overlay
007	33001132	<a href="#">33002342</a>		Plug, Sifht Hole
"	33001168		Not Available	PLUG, SIGHT HOLE (ALM)
008	<a href="#">33001977</a>			Fastener, Control Panel
009	<a href="#">33001156</a>			Button, Control
010	<a href="#">33001201</a>			Plate, Control Mounting
011	33001200	<a href="#">33002449</a>		Switch, Membrane
012	33001747	<a href="#">33002605</a>		Circuit Board Assembly

013	<a href="#">33001204</a>		Stand-Off, Ccontrol Board
"	<a href="#">912077</a>		Locknut, Reader Harness
014	<a href="#">215506</a>		Screw, Control Panel Overlay
"	<a href="#">33001978</a>		Panel, Access
"	33001979	<a href="#">33001978</a>	Panel, Access
"	<a href="#">33001980</a>		Fastener, Access Panel
"	<a href="#">33002004</a>		Clip, Fastener
015	Y206081	<a href="#">W10116737</a>	Lock
016	213750	<a href="#">W10133266</a>	Cam-Lock
017	<a href="#">33001981</a>		Wire, Ground
018	33002117	<a href="#">208042</a>	Switch, Sensor
019	912012	<a href="#">3400409</a>	Screw
020	<a href="#">33001982</a>		Bracket, Switch Mounting
021	<a href="#">33002052</a>		Wire Harness, Main
022	<a href="#">33002060</a>		Bracket, Security
023	<a href="#">22001995</a>		Screw Note: Screw, Tumbler Front And Shroud
"	NLA	Not Available	NUT, SECURITY

