


Maytag MUG15PDAWA 03 - CABINET-FRONT (UPPER)



Maytag Residential Maytag MUG15PDAWA Dryer Parts Parts Diagram 03 - CABINET-FRONT (UPPER)
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	33001995	33002124		Cover, Top
"	NLA		Not Available	(ALM)
002	33001997			Plug, Hole
003	22001883	214354		Screw, Top Cover To Cabnt.
004	33001998			Bracket, Top Cover
"	33001999			Bracket, Top Cover
005	22001995			Screw Note: Screw, Tumbler Front And Shroud
006	NLA		Not Available	BRACKET, TERMINAL BLOCK---NA
007	22001995			Screw Note: Screw, Tumbler Front And Shroud
008	NLA		Not Available	SCREW, GROUND LUG
009	NLA		Not Available	WASHER, GROUND LUG
010	22001502			Fastener, U-NUt
011	NLA		Not Available	CABINET (WHT)
012	33001980			Fastener, Access Panel

013	Y313561		Screw---NA
"	33002002		Bracket, Switch
"	Y310632	1163839	Screw
014	206824	W10133335	Relay, Motor
"	Y251119	3177991	Screw
015	213007		Xfor Cabinet See Cabinet, Back
016	33001991		Bolt, Carriage

