

# Maytag MUG15PDAWW 04 - DOOR (UPPER)



Maytag [Residential Maytag MUG15PDAWW Dryer Parts](#) Parts Diagram 04 - DOOR (UPPER)  
 Click on the part number to view part

| Item | Original Part Number     | Replaced By              | Status        | Part Description             |
|------|--------------------------|--------------------------|---------------|------------------------------|
| 001  | <a href="#">33002015</a> |                          |               | Door, Outer                  |
| "    | NLA                      |                          | Not Available | (ALM)                        |
| 002  | <a href="#">22002063</a> |                          |               | Screw No.8-18AB Wafer Head   |
| "    | 22002064                 | <a href="#">489355</a>   |               | Screw, 8 X 1/2               |
| 003  | <a href="#">33002017</a> |                          |               | Hinge, Door                  |
| 004  | 22002062                 | <a href="#">98006631</a> |               | Screw                        |
| 005  | 22002300                 | <a href="#">9740848</a>  |               | Screw, Mixing Valve Mounting |
| "    | 33002018                 | <a href="#">33002780</a> |               | Door Tunnel W` Handle        |
| "    | 33002019                 | <a href="#">33002781</a> |               | Door Tunne                   |
| 006  | <a href="#">33002020</a> |                          |               | Door, Inner W/Seal           |
| "    | NLA                      |                          | Not Available | (ALM)                        |
| 007  | <a href="#">22002038</a> |                          |               | Clip, Door                   |
| 008  | <a href="#">33001763</a> |                          |               | Plug, Inner Door             |
| 009  | <a href="#">33002094</a> |                          |               | Seal, Door                   |
| 010  | <a href="#">22002039</a> |                          |               | Clip, Door                   |
| 011  | <a href="#">33001761</a> |                          |               | Strike, Door                 |

|     |                          |                          |                          |
|-----|--------------------------|--------------------------|--------------------------|
| 012 | <a href="#">33001793</a> |                          | Bracket, Strike          |
| 013 | 33002022                 | <a href="#">33002607</a> | Lens, Door               |
| "   | <a href="#">33002607</a> |                          | Lens, Door               |
| 014 | <a href="#">33002038</a> |                          | Switch, Door             |
| 015 | 33001711                 | <a href="#">33002936</a> | Medallion-               |
| "   | 33002023                 | <a href="#">33002081</a> | Panel, Front             |
| "   | 33002024                 |                          | Not Available            |
| "   | 33002051                 |                          | Not Available            |
| 016 | 33001486                 | <a href="#">98008544</a> | Screw                    |
| 017 | 33001791                 | <a href="#">306436</a>   | Door Latch Kit--W        |
| 018 | <a href="#">33002025</a> |                          | Twin Speednut            |
| 019 | <a href="#">33001175</a> |                          | Cover, Hinge Hole        |
| "   | <a href="#">33001176</a> |                          | Cover, Hinge Hole        |
| 020 | <a href="#">33002026</a> |                          | Extension, Tumbler Front |
| 021 | <a href="#">33001767</a> |                          | Seal, Shroud             |
| 022 | 33001855                 | <a href="#">33002917</a> | Screw, No.10-16          |

