


Maytag MUG15PDAXW 02 - CONTROL CENTER



Maytag [Residential Maytag MUG15PDAXW Dryer Parts](#) Parts Diagram 02 - CONTROL CENTER
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	33001984	Y33001983		Box, Coin
"	Y33001983			Box, Coin
002	33001987			(ALM)
"	Y33001986			Vault, Coin
003	212707	3196385		Screw
004	Y052740	62739		Nut, Lock
005	Y052734			Nut, Carrage Bolts And Bracket
006	312535			Washer, Vault Mounting Brk.
"	NLA		Not Available	WASHER, VAULT MOUNTING BRK.
007	314635			Chute, Coin
008	33001250			Switch, Vault And Service Door
009	NLA		Not Available	NUT, CAGE
010	22001810		Not Available	STRAP, MOUNTING
011	33001989			Retainer, Vault Switch

012	33001990		Bracket, Mounting Vault
013	33001991		Bolt, Carriage
014	216200		Face Plate Return Button
"	22001875		Coin Drop Assembly-Dual
"	22002144		Single Faceplate
"	22002535	W10133245	Dual Coin Drop Assembly
"	22003815		Dual Faceplate
015	314665		Screw, Switch Assembly
"	33001985		Switch, Optic
016	33001992		Bracket, Coin Drop Mount.
"	33001993	33001992	Bracket, Coin Drop Mount.
017	Y313561		Screw---NA
"	910181		Lockwasher, Terminal Block

the laundry company[®]

the laundry company[®]

the laundry company[®]