


# Maytag MVWC200XW0 01 - TOP AND CABINET PARTS



Maytag Residential Maytag MVWC200XW0 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10240509</a>			Installation Instructions
"	W10280548		Not Available	USE & CARE GUIDE
"	W10280489		Not Available	INSTALLATION (TECH SHEET)
"	W10062940		Not Available	ENERGY GUIDE
2	<a href="#">W10251325</a>			Top
3	<a href="#">W10338623</a>			Lid
4	<a href="#">9724509</a>			Bumper, Lid
5	<a href="#">9740848</a>			Screw, Mixing Valve Mounting
6	<a href="#">91770</a>			Hinge, Lid
7	W10119872	<a href="#">W10119828</a>		Screw, Lid Hinge Mounting
8	<a href="#">W10240513</a>			Strike, Lid Lock
9	<a href="#">W10273971</a>			Screw, 6-19 X 1/2
10	<a href="#">W10192089</a>			Dispenser, Bleach
11	W10240511	<a href="#">W10392041</a>		Bezel, Lid Lock
12	<a href="#">21258</a>			Bearing, Lid Hinge
13	<a href="#">90016</a>			Clip, Pressure Switch Hose

14	W10238287	<a href="#">W10404050</a>	Latch
15	<a href="#">8281163</a>		Screw, Dispenser Housing Mounting
16	<a href="#">W10250884</a>		Panel Rear
17	W10251994	<a href="#">W10338650</a>	Cabinet
18	<a href="#">W10215098</a>		Brace, Cabinet Top Front
19	<a href="#">W10215099</a>		Brace, Cabinet Top Rear
20	1157158	<a href="#">489069</a>	Xxscrew, 10-12 X 1/2
21	<a href="#">W10248088</a>		Lock, Top
22	W10335586	<a href="#">W10397767</a>	Foot Assembly, Leveling
23	<a href="#">W10215102</a>		Hinge, Top
24	W10142728	<a href="#">3370225</a>	Screw
25	<a href="#">W10215139</a>		Cover, Harness
26	<a href="#">3400076</a>		Screw, Bracket Mounting
27	<a href="#">W10221546</a>		Hose, Outer Drain Assembly
28	<a href="#">W10280024</a>		U-Bend, Drain Hose
29	<a href="#">356138</a>		Clamp, Hose
30	<a href="#">W10339879</a>		Tie, Cable

