


Maytag MVWC500VW1 03 - AGITATOR, BASKET AND TUB PARTS



Maytag Residential Maytag MVWC500VW1 Washer Parts Parts Diagram 03 - AGITATOR, BASKET AND TUB PARTS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8575076	8575076A		Dispenser
2	3354733	W10074580		Cap, Barrier
3	W10072840			Fabric Softener
4	358237			Screw And Washer
5	3949550			Washer
6	W10093672			Agitator
7	3363663	285811		Cam-Agitator
8	3366877	80040		Dog-Agitator
9	3363661			Bearing, Driven Cam
10	3349019			Auger, Agitator
11	3350389	285587		Washer
12	W10110020			Agitator
13	W10168523			Tub Ring And Gasket
14	3359585	3976308		Gasket, Tub Ring
15	3354845			Clip, Agitator
16	8543666			Washer, Agitator

17	W10006326		Balance Ring
18	W10116602		Nut, Spanner
19	W10006327		Basket And Balance Ring
20	2219077		Clip, Pressure Switch Hose
21	3347780	353244	Hose, Pressure Switch
22	389140		Tub Block, Basket Drive
23	63849		Strain Relief, Power Cord
24	383727		Gasket, Centerpodt

