


Maytag MVWX700XL0 01 - TOP AND CABINET PARTS



Maytag Residential Maytag MVWX700XL0 Washer Parts Parts Diagram 01 - TOP AND CABINET PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10240509			Installation Instructions
"	W10240510		Not Available	INSTALLATION INSTRUCTIONS (SPANISH)
"	W10280465		Not Available	USE & CARE GUIDE
"	W10280504		Not Available	INSTRUCTIONS, SOUND SHIELD INSTALLATION
"	W10240504		Not Available	TECH SHEET IMPROVED WASH
"	W10280498		Not Available	QUICK START GUIDE
"	W10062924		Not Available	ENERGY GUIDE
2	W10238290			Top
"	W10268719			Top
3	W10296171			Lid
"	W10296172			Lid
4	9724509			Bumper, Lid
5	W10270398			Hinge, Spring Assembly
"	W10270399			Hinge, Spring Assembly

6	W10177046		Cabinet - Damper, Sound
7	693995		Screw, Hex Head
8	W10238327		Strike, Lid Lock
"	W10238329		Strike, Lid Lock
9	9740848		Screw, Mixing Valve Mounting
10	W10240977		Dispenser, Bleach
"	W10304138		Dispenser, Bleach
11	W10240511	W10392041	Bezel, Lid Lock
"	W10240512	W10392092	Bezel, Lid Lock
12	W10293653		Bearing, Lid Hinge
"	W10293293		Bearing, Lid Hinge
13	90016		Clip, Pressure Switch Hose
14	W10238287	W10404050	Latch
15	8281163		Screw, Dispenser Housing Mounting
16	356138		Clamp, Hose
17	W10319849	W10338650	Cabinet
"	W10319854	W10338651	Cabinet
18	W10215098		Brace, Cabinet Top Front
19	W10215099		Brace, Cabinet Top Rear
20	1157158	489069	Xxscrew, 10-12 X 1/2
21	W10248088		Lock, Top
22	W10335586	W10397767	Foot Assembly, Leveling
23	W10250884		Panel Rear
24	W10215102		Hinge, Top
25	W10142728	3370225	Screw
26	W10215139		Cover, Harness
27	3400076		Screw, Bracket Mounting
28	W10317148	W10319260	Sound Absr
29	W10221546		Hose, Outer Drain Assembly
30	W10280024		U-Bend, Drain Hose
31	8563965		Hinge Wire
"	8572974		Hinge Wire
32	W10078270		Screw, Lid Hinge Mounting
33	W10323735		Badge

