


Maytag MVWX700XW1 02 - CONSOLE AND DISPENSER PARTS

CONSOLE AND DISPENSER PARTS

For Models: MVWX700XW1, MVWX700XL1
(White) (Silver)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

W10413278

3

Maytag [Residential Maytag MVWX700XW1 Washer Parts](#) Parts Diagram 02 - CONSOLE AND DISPENSER PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10293207			Console
"	W10293208			Console
2	W10251381			Knob, Control
"	W10251384			Knob, Control
3	W10272638			User Interface
4	W10219342			Screw, Baffle Mounting
5	8312709			Clip-Console
6	W10405819			Control Unit Assembly, Machine And Motor
7	W10269597			Panel, Console Rear Cover
8	3390647	488729		Screw
9	1157158	489069		Xxscrew, 10-12 X 1/2
10	W10280079			Seal, Console
11	W10266797			Cord, Power
12	3400076			Screw, Bracket Mounting
13	W10240963	W10432327		Housing Assembly - Dispenser
14	W10240949			Valve, Cold Water Inlet

15	W10240948	Valve, Hot Water Inlet	
16	W10240967	Harness, Valve	
17	3400061	Screw, Dispenser Housing Mounting	
18	97787	W10109200	Screw, Baffle Mounting
19	W10240946	Bezel, Dispenser	
20	W10240960	Drawer, Dispenser Assembly	
21	W10285492	Harness, User Interface	
22	9740848	Screw, Mixing Valve Mounting	
23	W10326923	Spacer, Knob	
24	8536939	Clip, Knob	
25	W10274524	Tensioner, Facia	
26	W10305134	Bezel, Cycle Trim	
27	3196172	Screw, 6-19 X 3/8	

the laundry company[®]

the laundry company[®]

the laundry company[®]