


Maytag PAV3200AGW 03 - CONTROL PANEL



Maytag [Residential Maytag PAV3200AGW Washer Parts](#) Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	21001700			Panel, Control
2	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	21001641	21001519		Endcap
3	21001630	21001523		Endcap
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	21001491			Switch, Water Temperature
5	21001625	21001741		Switch, Pressure
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	21001600			Skirt, Timer
7	21001594	21001972		Knob, Timer
8	25-7851			Speedclip, End Cap To Top
9	21001640	21002005		Frame, Control Panel
10	25-3457			Screw, Sems

"	25-7933		Ring, Retaining
"	21001527		Shield, Rear
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
11	21001701		Timer
"	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
12	21001525	21002196	Knob-Selector
13	21001603		Shield, Control
"	21001517		Shield, Control
"	53-2504	31001193	Pad, Shield
14	21001687		Switch, Speed
15	31001443		Switch, Two Pos Rotary
16	21001419	Not Available	MANUAL, LAUNDERING TIPS
"	21001702	Not Available	MANUAL, USE & CARE
17	12002417		Wire Kit

