


# Maytag PAV3240AWW 05 - CONTROL PANEL



Maytag [Residential Maytag PAV3240AWW Washer Parts](#) Parts Diagram 05 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">21001828</a>			Panel, Control
2	<a href="#">21001519</a>			Endcap
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	<a href="#">21001523</a>			Endcap
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
4	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001226</a>			Switch, Water Temp. 4 Position
5	<a href="#">21001554</a>			Switch, Water Level
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">21001882</a>			Switch, Pressure
6	<a href="#">21001600</a>			Skirt, Timer
7	21001594	<a href="#">21001972</a>		Knob, Timer
8	21001140	<a href="#">21001898</a>		Switch, Speed

9	21001745	Not Available	FRAME (WHT)
10	<a href="#">21001527</a>		Shield, Rear
"	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
11	<a href="#">21001595</a>		Timer
"	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
12	21001525	<a href="#">21002196</a>	Knob-Selector
13	<a href="#">21001603</a>		Shield, Control
14	<a href="#">21001813</a>		Switch, Rocker
15	<a href="#">21001718</a>		Manual, Use And Care
16	<a href="#">21001805</a>		Harness, Wire
17	<a href="#">21001805</a>		Harness, Wire
"	<a href="#">21001947</a>		Harness, Wiring
18	<a href="#">12002417</a>		Wire Kit

