


# Maytag PAV3250AWW 03 - CONTROL PANEL



Maytag [Residential Maytag PAV3250AWW Washer Parts](#) Parts Diagram 03 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">21001700</a>			Panel, Control
2	<a href="#">21001519</a>			Endcap
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	<a href="#">21001523</a>			Endcap
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
4	<a href="#">21001226</a>			Switch, Water Temp. 4 Position
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
5	21001625	<a href="#">21001741</a>		Switch, Pressure
"	25-3092	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
6	<a href="#">21001600</a>			Skirt, Timer
7	21001594	<a href="#">21001972</a>		Knob, Timer
8	<a href="#">25-7851</a>			Speedclip, End Cap To Top
9	21001604		Not Available	FRAME, CONTROL PANEL (WHT)

10	<a href="#">21001517</a>		Shield, Control
"	<a href="#">21001603</a>		Shield, Control
"	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-7853	<a href="#">25-7933</a>	Ring, Retaining
"	<a href="#">25-3457</a>		Screw, Sems
11	25-3092	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
"	21001490	Not Available	SLEEVE, VINYL (AUST)
"	<a href="#">21001595</a>		Timer
12	21001525	<a href="#">21002196</a>	Knob-Selector
13	<a href="#">31001193</a>		Pad, Shield
"	53-2504	<a href="#">31001193</a>	Pad, Shield
14	21001173	<a href="#">21001687</a>	Switch, Speed
15	<a href="#">31001190</a>		Switch, Two Position Rotary
16	21001618	Not Available	MANUAL, USE & CARE
17	<a href="#">12002417</a>		Wire Kit

