


Maytag PAV3300AWW 05 - CONTROL PANEL



Maytag Residential Maytag PAV3300AWW Washer Parts Parts Diagram 05 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	21001730			Panel, Control
2	21001519			Endcap
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	21001523			Endcap
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	21001226			Switch, Water Temp. 4 Position
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
5	21001882			Switch, Pressure
"	21001554			Switch, Water Level
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	21001600			Skirt, Timer
7	21001594	21001972		Knob, Timer
8	25-7851			Speedclip, End Cap To Top

9	21001745		Not Available	FRAME (WHT)
10	25-7853	25-7933		Ring, Retaining
"	21001527			Shield, Rear
"	25-3457			Screw, Sems
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
11	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	21001595			Timer
"	21001490		Not Available	SLEEVE, VINYL (AUST)
12	21001525	21002196		Knob-Selector
13	53-2504	31001193		Pad, Shield
"	31001193			Pad, Shield
14	21001227	21001673		Switch, Speed 4 Pos Rotary
15	21001714	21001813		Switch, Rocker
17	21001718			Manual, Use And Care
18	21001805			Harness, Wire
"	21001947			Harness, Wiring
21	12002417			Wire Kit

