


Maytag PAV3300AWW 09 - TUB



Maytag Residential Maytag PAV3300AWW Washer Parts Parts Diagram 09 - TUB
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|--------------------------|---------------------------|---------------|------------------------------|
| 1 | 21001593 | 21001878 | | Auger/Post Assembly |
| 2 | 21001510 | 22002947 | | Bolt, Tub |
| 3 | 25-7953 | 22002933 | | Screw |
| 4 | 25-7948 | W10309247 | | Screw |
| 5 | 35-3685 | | | Gasket, Basket To Centerpost |
| 6 | 35-3686 | | | Gasket, Tub To Housing |
| 7 | 25-7967 | 3400504 | | Screw |
| 8 | 35-2328 | | | Seal, Tub Top |
| 9 | 21001905 | | | Dispenser, Fabric |
| 10 | 21001529 | | | Basket Assembly |
| 11 | 35-2978 | | | Seal, Tub/Housing |
| 12 | 35-3700 | | | Tub Assembly |
| 13 | 21001531 | | Not Available | TOP, TUB (PLASTIC) |
| 14 | 21001530 | | | Base, Agitator |