


Maytag PAV5057AWW 03 - CONTROL PANEL



Maytag Residential Maytag PAV5057AWW Washer Parts Parts Diagram 03 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	21001928		Not Available	PANEL, CONTROL (WHT)
2	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	21001519			Endcap
3	21001523			Endcap
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	21001852			Switch, Temperature
5	21001882			Switch, Pressure
6	21001600			Skirt, Timer
7	21001594	21001972		Knob, Timer
8	21001227	21001673		Switch, Speed 4 Pos Rotary
9	21001745		Not Available	FRAME (WHT)
10	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	25-3457			Screw, Sems
"	21001527			Shield, Rear

11	25-3092	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	21001929		Timer
12	21001525	21002196	Knob-Selector
13	21001517		Shield, Control
"	21001603		Shield, Control
14	31001397		Buzzer
15	21001813		Switch, Rocker
16	35-6696	Not Available	MANUAL, USE & CARE
17	21001931	Not Available	HARNES, WIRING

